

EURO	US MENS	US WOMENS	UK	MONDO
34.5	3	4	2	
35	3.5	4.5	2.5	21.5
35.5	4	5	3	22
36	4.5	5.5	3.5	22.5
36.5	5	6	4	23
37	5.5	6.5	4.5	23.5
37.5	6	7	5	24
38	6.5	7.5	5.5	24.5
38.5	7	8	6	25
39	7.5	8.5	6.5	25.5
39.5	8	9	7	26
40	8.5	9.5	7.5	26.5
40.5	9	10	8	27
41	9.5	10.5	8.5	27.5
41.5	10	11	9	28
42	10.5	11.5	9.5	28.5
42.5	11	12	10	29
43	11.5	12.5	10.5	29.5
43.5	12	13	11	30
44	12.5	13.5	11.5	30.5
44.5	13	14	12	31
45	13.5	14.5	12.5	31.5
45.5	14	15	13	32
46	14.5	15.5	13.5	32.5
46.5	15	16	14	33

All SCARPA non-plastic footwear uses European sizing

- * 1 Euro whole size = 6.6 mm = 0.26 inches
- * 1 US whole size = 8.4 mm = 0.33 inches
- * The 30 Euro sizes above cover the same size range as 24 US sizes.
- * More Euro sizes provide a better, more precise fit for your intended use.

Rock Shoes: downsize 1/2 to 2 full sizes from street shoe size

- * downsizing depends on model, intended use, and personal preference.

Mountaineering: Upsize (1/2+ sizes) depending on desired fit

- * SCARPA plastic mountaineering boots are based on the UK sizing scale.

Ski Boots: All SCARPA ski boots are measured in Mondo sizing

- * Highlighted (or not) sizes share the same shell size; the liners are lasted for each 1/2 size. Some skiers may want to downsize up to 1 full Mondo size, depending upon personal preference.